


Base x1 (wood)

Top




Side



Sides x 2(wood)

Front




Side




Attachments (aluminium) x 4 – ‘Angle Bracket’

Top



Front



Other parts



- Fender / Penny washers (30mm diameter) x 16
- Split washers (30mm diameter) x 8
- Wood screws (for attachments) x 16
- Plastic three-prong knobs (60mm point to point) x 4
- Metal sleeve (85mm)
- Threaded bolt (160mm length, 6mm diameter) x 2

Materials needed – customwood or plywood

Extensions x 2 (wood)


Front

Back




Extensions continued

Side




Ramp x 1 (wood)

Front




Back



Ramp continued

Side



Base + Attachments

Top

